



NOTES:

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. Minimum Stile Width: 2 (51).
4. Maximum door Width: 42 (1067)
5. Prepare mounting holes when installing the hardware.
6. Provide adequate door support to maintain door integrity after bar installation with power tools, door use, or abuse.
7. Wood screws (by others) permitted for solid core wood doors if pilot holes are used for installation and door label allows its use.

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

620DB & 720DB Dummy Push Bar
Application for Wood or Composite Door

1-855-557-5078 Ext. 2
www.accentra-assaabloy.com

ACCENTRA
ASSA ABLOY

Experience a safer
and more open world

Copyright © 2015, 2024, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

| | | | |
|-----------------|-----------|----------------------|-------|
| SUPERSEDES | 05/15 | DO NOT SCALE DRAWING | |
| TEMPLATE NUMBER | 7470-1720 | SHEET | DATE |
| | | 1 of 1 | 06/24 |