ASSA ABLOY has transitioned the formerly Yale Commercial brand to ASSA ABLOY ACCENTRA<sup>™</sup>. This affects only the brand name; the products and product numbers will remain unchanged.

NOTES: 1. Do not scale drawing. Dimensions are in inches (mm). 2. LHR door shown. Preparation is typical for both door hands. 3. 4. Minimum door stile width: 3-1/2(89). 5. Prepare mounting holes when installing the device. 1-1/4 Minimum 6. Unreinforced frames require blind rivet nuts (by others) (32) mount the strike. Dimension from door face. 7 Strike Reinforcement 8. For outside trim preparation see appropriate trim template. (See Note 6) 9. Provide adequate structural support to maintain door integrity after device installation with power tools, door use, or abuse. 10. Device mount to hinge stile (not shown) requires hole location and preparation during device installation. Door structural require ments are similar for both door stiles. **INSIDE FACE OF DOOR** 11. For electrical devices (suffixes "-B", "-G", "-O", "-P", "-S") also see template 7477-0001. 12. Wood screws (by others) permitted for solid core wood doors if pilot holes are used for installation, when door label allows its use. Device: #14x1-1/2"RHWS, interlock: #10x1-1/2" FHWS. Vertical Reference 1-5/8 (41) (Note 7)  $\frac{5/8}{(16)}$ 5/8 (15.9) Dia. 1-11/32 x 5/8 (16) Deep 3-5/8 (34.1)This Face (92) Horizontal Reference 3-5/8 (Device & 1-11/32 (92) Strike Centerline) (34.1)10-24 Tap (2 Places) **Strike Preparation Detail** 3/8 (9.50) Dia. Thru (2 SNB Holes) <u>39-15/16</u> See Note 12 (1014)

MULLION NOTE: FOR MULLION MODEL NUMBERS M100(F) AND KRM100(F) REFER TO TEMPLATE NUMBER 7400-0100. FOR MULLION MODEL NUMBERS M200(F) AND KRM200(F) REFER TO TEMPLATE NUMBER 7400-0200. FOR MULLION MODEL NUMBERS M200FWS AND KRM200FWS REFER TO TEMPLATE NUMBER 7400-0210. Finished Floor

7200M & 7205M Rim Panic Devices RESPONSIBILITY DOOR AND FRAME MANUFACTURERS ARE for Narrow Escutcheon Trim - 757 Strike ACCENTRA RESPONSIBLE FOR PROVIDING ADEQUATE Application for Wood or Composite Door and CONSTRUCTION OR REINFORCEMENTS FOR H.M. Frame or Mullion with 757 Strike & SNB PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST (Not for Fire Labeled Devices) ASSA ABLOY BE INSTALLED ON PROPERLY REINFORCED 1-855-557-5078 Ext. 2 DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION www.accentra-assaabloy.com SUPERSEDES DO NOT SCALE DRAWING 02/08 Experience a safer Copyright © 2008, 2023, 2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware TEMPLATE NUMBER Group, Inc. All rights reserved. Reproduction in whole or in part without the express written SHEET DATE and more open world permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited. 04/24 7473-1000 1 of 1