


1. This door marker is for Von Duprin 98/99, XP98/99, 98/9927 Exit Device.

2. Apply to outside face of door using knockout windows to locate centerlines.

3. If door thickness is other than 1-3/4", or backset is other than 2-3/4", do not place on edge. Find backset by measuring from the centerline of beveled edge.

4. Dimensions given in inches (millimeters).



Experience a safer
and more open world