



NOTES:

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Provide adequate structural support to maintain door integrity during operation.
6. Prepare mounting holes when installing trim.
7. Dimensions given about a centerline are symmetrical.



421F



Section X - X

<p>RESPONSIBILITY DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.</p>	<p>421F Trim With 1800(F), 6100(F) or 6170(F) Series Rim and Vertical Rod Exit Devices Wood Door Preparation 1-855-557-5078 Ext. 2 www.accentra-assaabloy.com</p>	<p>ACCNTRA ASSA ABLOY</p>
<p>Experience a safer and more open world</p>	<p>Copyright © 2013, 2024, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.</p>	<p>SUPERSEDES 12/23 DO NOT SCALE DRAWING TEMPLATE NUMBER 7400-1421 DATE 07/24</p>