



**Notes:**

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. For door reinforcement see template 7400-0000.
6. Prepare mounting holes when installing the trim.
7. 502(F), 504(F), and 505(F) trim require 3-1/2 (89) or wider door stiles.
8. Provide internal door support door deformation from bolting trim to the device
9. Template applies to 508F.

**RESPONSIBILITY**  
DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

502(F), 503(F), 504(F), 505(F), 506(F), 507(F), 508(F) & 509(F) Narrow Escutcheon Trim  
With 6200, 7200, 7200(M) or 7200MF Series Rim and Vertical Rod Exit Devices  
Metal Door Preparation  
1-855-557-5078 Ext. 2  
[www.accentra-assaabloy.com](http://www.accentra-assaabloy.com)

**ACCENTRA**  
**ASSA ABLOY**

Experience a safer  
and more open world

Copyright ©2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

SUPERSEDES	7400-0502 02/24	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7400-0502	SHEET	DATE
		1 of 1	04/24