



**NOTES:**

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Provide adequate structural support to maintain door integrity during operation.



**RESPONSIBILITY**  
 DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

**634F Trim**  
**With 1500(F), 2100(F), 6100(F) or 7100(F) Series**  
**Rim, Mortise and Vertical Rod Exit Devices**  
**Wood or Composite Door Preparation**  
**Contact us for support at 1-800-438-1951.**

**ASSA ABLOY**

SUPERSEDES 7400-1634 (05-15)	DO NOT SCALE DRAWING
TEMPLATE NUMBER	7400-1634
DATE	12-23