


Installation Instructions

ED2200 Series Rim Exit Devices



WARNING

This product can expose you to lead which is known to the state of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.

For installation assistance contact Corbin Russwin
1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com

Attention Installer

Any retrofit or other field modification to a fire rated opening can potentially impact the fire rating of the opening, and Corbin Russwin & Hardware makes no representations or warranties concerning what such impact may be in any specific situation. When retrofitting any portion of an existing fire rated opening, or specifying and installing a new fire-rated opening, please consult with a code specialist or local code official (Authority Having Jurisdiction) to ensure compliance with all applicable codes and ratings.

FM571 10/22

ED2200 Series

Rim Exit Devices




Installation Instructions

1 Product Overview

ED2200 (Panic Label)
ED2200A (Fire Label)

Note: These installation instructions cover standard product only. To install options, such as shim kits or interlock brackets, refer to the instructions packed with the optional component.




Dogging: Feature to hold bolts retracted and touchpad depressed. For push-pull door operation.

To Dog Device:

1. Insert dogging key.
 2. Hold touchbar depressed.
 3. Turn key 1/4 turn clockwise.
- (Not a feature of fire labeled devices.)

Packed for reinforced metal doors. Optional sex nuts required for unreinforced metal and composite wood doors and are furnished standard with all fire-rated devices.

Outside Trim: Device is packed ready for any applicable Corbin Russwin trim.



For installation assistance contact Corbin Russwin
1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com

Copyright © 2022, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

Installation Instructions

2 Maintenance

1. Periodically remove covers and coat mechanisms with a silicone base lubricant. This is particularly required in corrosive environments for proper product function.
2. Check mounting fasteners periodically. Retighten if found loose. Apply screw locking compound (available at automotive part stores) or change part fasteners if screws continue to back up.
3. Periodic checks (and adjustments) of strikes are required to compensate for changes in the opening (e.g. door sagging).

3 Pre-Installation


Unreinforced Doors or Frames

Doors and Frames with walls having a structural thickness (metal skin plus reinforcement or solid hardwood) to engage less than (3) full screw threads are considered unreinforced.


Unreinforced Doors: Use SNB (sex nuts and bolts).

Unreinforced Frames: Use Blind Rivet Nuts.

Recommended fasteners for unreinforced openings are not necessarily supplied by Corbin Russwin Security, Inc.



4 Mark Door



ED2200 Series

Rim Exit Devices





Installation Instructions

5 Prepare Door & Frame

1. Seat plastic template on door and stop faces.
2. Align horizontal and vertical centerlines.
3. Locate and tape Trim Template on door. (See instructions packed with Trim).
4. Spot and prepare holes.

Device: Each (2) 1/4-20 Machine Screws* OR (2) 3/8" (10) Dia. Optional Sex Nuts & Bolts. (*) Metal reinforced door only.

Strike: (2) 10-24 Machine Screws OR (2) #10 Wood Screws



6 Clear Raised Door Molding

Device (head bar and end cap) must seat flush on door surface or on shims that keep it parallel to door face.

(1) Shim Kit #697F338 required for each 1/4" (6mm) of raised molding. Longer mounting screws needed when more than one (1) Shim Kit is used. See instructions provided with shim kits for installation.



ED2200 Series

Rim Exit Devices


Installation Instructions

7 Mount Components


1. Mount Trim (Follow instructions packed with trim).
2. Mount Latch Case:
 - Use (2) 1/4-20 x 1" Phillips Round Head Machine Screws or SNB for ED2200.
 - Use (4) 1/4-20 x 1" Phillips Round Head Machine Screws or SNB for ED2200A.
3. Open door. Slide Bar over door surface until touching Latch Case wall. Slider in Latch Case penetrates into Bar. (See Detail 1)
4. Set Bar level.
5. Size Bar. To cut Bar, see Detail 2.
6. Reposition Bar (Detail 1). Clamp Bar with End Cap Bottom (See Detail 3). Locate End Cap Bottom mounting holes.
7. Prepare End Cap Bottom mounting holes. Mount End Cap Bottom (Detail 3). (2 ea. 1/4-20 Phillips Round Head Machine Screws or 3/8" (10) dia. SNB).



Detail 1: Fit Bar



Detail 2: To Cut Bar



Detail 3: Clamp Bar

Installation Instructions

7 Mount Components, continued.

8. Check Bolt Retraction

- Depress bar (bolts must retract). Release bar (bolts must extend).
- Actuate trim (bolts must retract). Release trim actuator (bolts must extend).
- Depress touchbar, turn dogging key clockwise (bar must remain depressed, bolts must remain retracted). Turn dogging key counterclockwise (bar and bolts must return to extended position).



9. Tighten all mounting screws.

Note: When resulting operation is faulty, check first for visible binding or interference. If there is no apparent reason for the fault, remove item from the door and recheck its operation before assuming that it is defective.


8 Install Strike

1. Position Strike Projection (Strike + Locking Plate + Shims, if needed). See Detail A.

2. Position Strike Depth. See Detail B.



3. Fasten Strike. See Detail C.



4. Check Bolt Engagement.

- Bolt should retract to clear the strike, when actuated by bar, trim, or dogging action. Bolt should consistently reengage the strike, when actuators are released and the door shuts.
- Door should remain latched and not rattle when pushed, pulled, or shaken in/out.

ED2200 Series

Rim Exit Devices




Installation Instructions

8 Install Strike, continued

5. (Required for Fire Devices only, Optional for Panic) Lock strike in place. See Detail D.



- Prepare for and install strike center screw (1 #10-24 PFHMS). See D1.



6. (Fire Mullion Installations only) Stabilize Strike. See Detail E.

- Position strike interlock bracket in place as shown. Locate bracket holes.



Interlock Bracket
Required for Fire Rated
Rim Exit Device with Mullion.



Note: Interlock bracket and screws supplied with Fire Mullion.

9 Install Head Cover & End Cap Top

(2) 8-32 x 5/16" PFHUMS
ED2200



*(1) 10-24 x 1/2" PPH "F" TCS



Corbin Russwin, Inc.
225 Episcopal Road
Berlin, CT 06037 USA
Phone: 800-543-3558
Fax: 800-447-6714
www.corbinrusswin.com

For installation assistance contact Corbin Russwin
1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com

FM571 10/22