

INSTALLATION INSTRUCTIONS 1100

Effective date: January 1, 2023
Supercedes: All Previous

ROCKWOOD

ASSA ABLOY

Experience a safer
and more open world

NOT TO SCALE

1100 CARRY OPEN BAR

1. Drill two $\frac{1}{4}$ " dia. holes thru inactive door.
2. Enlarge holes on opposite side to $\frac{3}{8}$ " dia.
3. Mount carry bar with 2ea. 12-24 screws and sex nuts. (Sex nuts fit a $1\frac{3}{4}$ " door)

