



REQUIRED HOLES	FUNCTION				
	PE8806 PE8804 PED5249 PED5247	PE8813 PE8815 PED5245 PED5210	PE8810 PE8840 PED5240 PED5250 PED5201	PE8873 PE8874 PED52910 PED52930	PE8875 PE8876 PED52903 PED52905 PED5267
HOLE 1		X		X	X
HOLE 2	X				X

NOTES:

1. TOLERANCE ON ALL DIMENSIONS  $\pm .031$ .
2. WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD.
3. SEE STRIKE TEMPLATE FOR VERTICAL CENTER LINE OF CHASSIS.
4. SEE MASTER SHEET No. MEDT23 FOR AREAS REQUIRING REINFORCEMENTS.
5. SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH.
6. FOR GLASS BEADED DOORS, IF BEAD CANNOT BE REMOVED, USE GLASS SHIM KIT (AVAILABLE ON ORDER).
7. SEE TRIM TEMPLATES FOR OUTSIDE FACE PREPARATION.
8. SEE TEMPLATES No. MEDT17 FOR ELECTROLYNX DETAILS WHEN NEEDED.

**ASSA ABLOY**  
Opening Solutions

Door Knob Locks  
Push Pull Handles  
Push Pull Latches

DOOR MANUFACTURERS TEMPLATE:  
RIM EXIT DEVICE

RELEASE DATE

02/12/25

TEMPLATE NO.

MEDT44\_4