



## 7800 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
<a href="#">Main Lock Template</a> <a href="#">Doc# 7057</a>	Mounting Template	This can be used for indicator and standard locks (Always Need This - Unless using Behavioral Health Trim)
<a href="#">Rose Trim Template</a> <a href="#">Doc# 7058</a>	Sectional/Roses	Works for all Roses (O, CO, TO, LN, CR, TR, E2, E3, E4, L, SN, SL)
<a href="#">Dummy Trim Template</a> <a href="#">Doc# 4298</a>	Sectional/Roses	Trim one side Kit Functions 93 & 94
<a href="#">50- Prefix Secured Indicator Rose Template</a> <a href="#">Doc# 7682</a>	Sectional Accessories/ Indicators	Includes 1- prefix, 74- prefix, & RX- Prefix    Available for the following functions: 24, 25, 26, 28, 29, 30, 36, 37, 38, 39, 40, 41, 43, 45, 50, 51, 52, 57, 58, 67 - with Rose Trim only
<a href="#">Thumbturn Template</a> <a href="#">Doc# 7059</a>	Sectional Accessories/ Indicators	7805, 7812, 7824, 7825, 7828, 7843, 7845, 7847, 7850, 7851, 7856, 7857, 7858, 7865, 7866, 7867, 7868, NAC-(78280, 78281, 78284, 78285)
<a href="#">Sectional Indicator Template</a> <a href="#">Doc# A7623</a>	Sectional Accessories/ Indicators	<b>For 185c:</b> Functions and Roses available: <ul style="list-style-type: none"> <li>• 30, 36 &amp; 37 Functions with 7800, 8200 and R8200 locks, CR, L, LN, TR, E &amp; O Roses</li> <li>• 26, 29, 38, 39, 40 and 41 Functions with 7800, 8200, and R8200 locks &amp; LN Roses Only</li> </ul> <b>For 185P:</b> Functions and Roses available: <ul style="list-style-type: none"> <li>• 65, 66, 68 Functions with 7800, 8200, and R8200 locks, CR, E, L, LN, O &amp; TR Roses</li> </ul>
<a href="#">Sectional Indicator Template</a> <a href="#">Doc# 4747</a>	Sectional Accessories/ Indicators	For V series Indicators (V01, V20, etc) Functions: 7805, 7812, 7820, 7821, 7822, 7824, 7825, 7826, 7828, 7829, 7830, 7836, 7837, 7838, 7839, 7840, 7841, 7842, 7843, 7845, 7846, 7847, 7850, 7851, 7852, 7856, 7857, 7858, 7859, 7865, 7866, 7867, 7868, PHR-NAC-78285 "
<a href="#">LE1, LE3, LW1, CE, TE, KE1, KE3, KW1 Trim Template</a> <a href="#">Doc# 7052</a>	Escutcheon Trims	Exposed Screws
<a href="#">LE2, LE4, KE2, KE4 Trim Template</a> <a href="#">Doc# 7052</a>	Escutcheon Trims	Concealed Screws
<a href="#">LS &amp; KS Trim Template</a> <a href="#">Doc# 7054</a>	Escutcheon Trims	Security Screws
<a href="#">WT Trim Template</a> <a href="#">Doc# 7055</a>	Escutcheon Trims	Surface Applied
<a href="#">VN1 Indicator Escutcheon Trim Template</a> <a href="#">Doc# 4746</a>	Escutcheon Indicators	Functions: 7805, 7812, 7820, 7821, 7822, 7824, 7825, 7826, 7828, 7829, 7830, 7836, 7837, 7838, 7839, 7840, 7841, 7842, 7843, 7845, 7846, 7847, 7850, 7851, 7852, 7856, 7857, 7858, 7859, 7865, 7866, 7867, 7868, NAC-PHR-78281, NAC-PHR-78285
<a href="#">PT Trim Template</a> <a href="#">Doc# 4512</a>	Behavioral Health (Anti-Ligature)	Functions: 7804, 7815, 7816, 7817, 7824, 7826, 7837, 7843, 7845, 7850, 7865
<a href="#">Curved/Straight Lip Strikes</a> <a href="#">Doc# 7064</a>	Strikes	
<a href="#">877 Open Back Strike Template</a> <a href="#">Doc# 4744</a>	Strikes	



**7800 Series Mortise Lock Installation Instructions**

Installation Instructions Name & Doc#	Installation Category	Installation Notes
Main Installation <a href="#">Doc# A7772</a>	Lockbody/Trim Related Installation Instructions	All Functions (Even Electrified)
Secured Indicator Rose and Retrofit Kit Installation <a href="#">Doc# A7671</a>	Lockbody/Trim Related Installation Instructions	50- Prefix 185S Retrofit Kit
Anti Vandal Trim Installation <a href="#">Doc# A7635</a>	Lockbody/Trim Related Installation Instructions	AV- prefix 667 Anti Vandal Trim Kit
Trim One Side Kit Installation <a href="#">Doc# A7028</a>	Lockbody/Trim Related Installation Instructions	
Dummy Trim (One Side) Installation <a href="#">Doc# A7036</a>	Lockbody/Trim Related Installation Instructions	7893 Function ONLY
7800 Knobs / 8200 Levers Mortise Lock & 3P8225 Levers Triad Lock with Escutcheon Trim - WT Designs Installation <a href="#">Doc# A7034</a>	Lockbody/Trim Related Installation Instructions	
6300 Series Core Removal and Installation <a href="#">Doc# A5634</a>	Cylinder/Thumbturn Related Instructions	Large Format Interchangeable Core (LFIC)
130 Series Thumbturn and 184 Emergency Release <a href="#">Doc# A5675</a>	Cylinder/Thumbturn Related Instructions	
Visual Occupancy Indicators Installation <a href="#">Doc# A7623</a>	Sectional Indicators	185C, 185P and 49- Prefix
Electrified Functions and Monitoring Electrolynx Connector System Installation <a href="#">Doc# A7722</a>	Electrical Related Instructions	Electrified Functions: 70,71, 72, 73 Monitoring Prefixes: RX, LX, DX
677 & 2-677 Rabbeted Door Kits Installation <a href="#">Doc# A7066</a>	Misc. Instructions	



**MORTISE LOCKS**

# Template and Installation Instruction Guide

91065

## 7900 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
<a href="#">Main Lock Template</a> <a href="#">Doc# 4589</a>	Mounting Template	This can be used for indicator and standard locks (Always Need This - Unless using Behavioral Health Trim)"
<a href="#">IN Series Template</a> <a href="#">Doc# 4713</a>	Access Control	Functions: 7978, 7979
<a href="#">Rose Trim Template</a> <a href="#">Doc# 7058</a>	Sectional/ Roses	Works for all Roses (O, CO, TO, LN, CR, TR, E2, E3, E4, L, SN, SL)
<a href="#">Dummy Trim Template</a> <a href="#">Doc# 4298</a>	Sectional/ Roses	Trim one side Kit Functions 93 & 94
<a href="#">Thumbturn Template</a> <a href="#">Doc# 7059</a>	Sectional Accessories/ Indicators	7805, 7812, 7824, 7825, 7828, 7843, 7845, 7847, 7850, 7851, 7856, 7857, 7858, 7865, 7866, 7867, 7868, NAC-(78280, 78281, 78284, 78285)
<a href="#">LE1, LE3, LW1, CE, TE, KE1, KE3, KW1 Trim Template</a> <a href="#">Doc# 7052</a>	Escutcheon Trims	Exposed Screws
<a href="#">WT Trim Template</a> <a href="#">Doc# 7055</a>	Escutcheon Trims	Surface Applied
<a href="#">PT Trim Template</a> <a href="#">Doc# 4512</a>	Behavioral Health (Anti-Ligature)	Functions: 7804, 7815, 7816, 7817, 7824, 7826, 7837, 7843, 7845, 7850, 7865
<a href="#">Curved/Straight Lip Strikes</a> <a href="#">Doc# 7064</a>	Strikes	
<a href="#">877 Open Back Strike Template</a> <a href="#">Doc# 4744</a>	Strikes	



## 7900 Series Mortise Lock Installation Instructions

Installation Instructions Name & Doc#	Installation Category	Installation Notes
Main Installation <a href="#">Doc# A8151</a>	Lockbody/Trim Related Installation Instructions	IN120 and IN220
Main Installation Aperio Installation <a href="#">Doc# A8190</a>	Lockbody/Trim Related Installation Instructions	
IN100 Series EM01 Outside Escutcheon & Controller Replacement Installation <a href="#">Doc# A8293</a>	Electrical Related Instructions	
Door Position Switch Installation <a href="#">Doc# A7983</a>	Electrical Related Instructions	FRAME ONLY
Door Position Switch Installation <a href="#">Doc# A8005</a>	Electrical Related Instructions	HINGE ONLY
IN120 Passport 1000 P2 Series Wifi Enabled Installation <a href="#">Doc# WFMN10A</a>	Electrical Related Instructions	



## 8200 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
<a href="#">Main Lock Template</a> <a href="#">Doc# 7057</a>	Mounting Template	This can be used for electrical, indicator, and standard locks (Always Need This - Unless using Behavioral Health Trim)
<a href="#">Electrified Lock Template</a> <a href="#">Doc# 7065</a>	Electrified	Typically paired with Main Lock Template Doc# 7057 (FOR FUNCTIONS 70 THRU 73) & (PREFIXES: 56-, RX-, LX- & DX-) & (NAC-270/271/274/275/280/281)
<a href="#">KP Series Template</a> <a href="#">Doc# 4514</a>	Access Control	Functions: 8276, 8277, 8278, 8279
<a href="#">SN Series Template</a> <a href="#">Doc# 4702</a>	Access Control	Functions: 82274, 82275, 82284, 82285, 82270, 82271, 82280, 82281
<a href="#">IN Series Template</a> <a href="#">Doc# 4713</a>	Access Control	Functions: 82276, 82277, 82278, 82279
<a href="#">Rose Trim Template</a> <a href="#">Doc# 7058</a>	Sectional/Roses	Works for all Roses (O, CO, TO, LN, CR, TR, E2, E3, E4, L, SN, SL)
<a href="#">Dummy Trim Template</a> <a href="#">Doc# 4298</a>	Sectional/Roses	Trim one side Kit Functions 93 & 94
<a href="#">Roseless Trim Template (R8200)</a> <a href="#">Doc# 4647</a>	Sectional/Roses	Discontinued so this one is optional -- For RX- PREFIX, H1/H2 - & HT PREFIX, & Standard R8200
<a href="#">50- Prefix Secured Indicator Rose Template</a> <a href="#">Doc# 7682</a>	Sectional Accessories/Indicators	Includes 1- prefix, 74- prefix, & RX- Prefix    Available for the following functions: 24, 25, 26, 28, 29, 30, 36, 37, 38, 39, 40, 41, 43, 45, 50, 51, 52, 57, 58, 67 - with Rose Trim only
<a href="#">Thumbturn Template</a> <a href="#">Doc# 7059</a>	Sectional Accessories/Indicators	8203, 8205, 8212, 8221, 8222, 8223, 8224, 8225, 8228, 8243, 8245, 8247, 8250, 8251, 8256, 8257, 8258, 8265, 8266, 8267, 8268, NAC-(82280, 82281, 82284, 82285)
<a href="#">Sectional Indicator Template</a> <a href="#">Doc# A7623</a>	Sectional Accessories/Indicators	<b>For 185c:</b> Functions and Roses available: <ul style="list-style-type: none"> <li>• 30, 36 &amp; 37 Functions with 7800, 8200 and R8200 locks, CR, L, LN, TR, E &amp; O Roses</li> <li>• 26, 29, 38, 39, 40 and 41 Functions with 7800, 8200, and R8200 locks &amp; LN Roses Only</li> </ul> <b>For 185P:</b> Functions and Roses available: <ul style="list-style-type: none"> <li>• 65, 66, 68 Functions with 7800, 8200, and R8200 locks, CR, E, L, LN, O &amp; TR Roses</li> </ul>
<a href="#">Sectional Indicator Template</a> <a href="#">Doc# 4747</a>	Sectional Accessories/Indicators	<b>For V series Indicators (V01, V20, etc)</b> Functions: 8205, 8212, 8220, 8221, 8222, 8224, 8225, 8226, 8228, 8229, 8230, 8236, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8250, 8251, 8252, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, PHR-NAC-82281, PHR-NAC-82285"



**8200 Series Mortise Lock Templates (cont.)**

Template Name & Doc Number	Category	Notes
<a href="#">LE1, LE3, LW1, CE, TE, KE1, KE3, KW1 Trim Template</a> <a href="#">Doc# 7052</a>	Escutcheon Trims	Exposed Screws
<a href="#">LE2, LE4, KE2, KE4 Trim Template</a> <a href="#">Doc# 7052</a>	Escutcheon Trims	Concealed Screws
<a href="#">LS &amp; KS Trim Template</a> <a href="#">Doc# 7054</a>	Escutcheon Trims	Security Screws
<a href="#">WT Trim Template</a> <a href="#">Doc# 7055</a>	Escutcheon Trims	Surface Applied
<a href="#">VN1 Indicator Escutcheon Trim Template</a> <a href="#">Doc# 4746</a>	Escutcheon Indicators	Functions: 8205, 8212, 8220, 8221, 8222, 8224, 8225, 8226, 8228, 8229, 8230, 8236, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8250, 8251, 8252, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, NAC-PHR-82281, NAC-PHR-82285
<a href="#">BHW Template</a> <a href="#">Doc# 4711</a>	Behavioral Health (Anti-Ligature)	Functions: 8204, 8205, 8215, 8216, 8217, 8224, 8225, 8226, 8227, 8228, 8229, 8230, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8248, 8249, 8250, 8251, 8252, 8255, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, 8270, 8271, 8272, 8273, 82270, 82271, 82274, 82275, 82280, 82281, 82284, 82285
<a href="#">BHL Template</a> <a href="#">Doc# 4745</a>	Behavioral Health (Anti-Ligature)	Functions: 8204, 8205, 8215, 8216, 8217, 8224, 8225, 8226, 8227, 8228, 8229, 8230, 8236, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8248, 8249, 8250, 8251, 8252, 8255, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, 8270, 8271, 8272, 8273
<a href="#">ALP Template</a> <a href="#">Doc# 4745</a>	Behavioral Health (Anti-Ligature)	Functions: 8204, 8205, 8206, 8213, 8215, 8216, 8217, 8224, 8225, 8226, 8227, 8228, 8229, 8230, 8231, 8235, 8236, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8248, 8249, 8250, 8251, 8252, 8255, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, 8270, 8271, 8272, 8273
<a href="#">Curved/Straight Lip Strikes</a> <a href="#">Doc# 7064</a>	Strikes	
<a href="#">Deadbolt Strike (78-0034)</a> <a href="#">Doc# 7064</a>	Strikes	Provided standard with deadlock functions 03, 20, 21, 22, 23, 28, 29, 30
<a href="#">877 Open Back Strike Template</a> <a href="#">Doc# 4744</a>	Strikes	



## 8200 Series Mortise Lock Installation Instructions

Installation Instructions Name & Doc#	Installation Category	Installation Notes
Standard Installation <a href="#">Doc# A7772</a>	Lockbody/Trim Related Installation Instructions	All Functions (Even Electrified)
KP8200 Installation <a href="#">Doc# A7373</a>	Access Control Instructions	ONLY Use this when using the KeyPad
IN100 Aperio Installation <a href="#">Doc# A8190</a>	Access Control Instructions	ONLY Use this when using the IN120 or IN220
IN120/IN220 Installation <a href="#">Doc# A8151</a>	Access Control Instructions	ONLY Use this when using the IN120 or IN220
SN Series Installation <a href="#">Doc# A8353</a>	Access Control Instructions	ONLY Use this when using the SN200 & SN220 Series Reader
Secured Indicator Rose and Retrofit Kit Installation <a href="#">Doc# A7671</a>	Lockbody/Trim Related Installation Instructions	50- Prefix 185S Retrofit Kit
Anti Vandal Trim Installation <a href="#">Doc# A7635</a>	Lockbody/Trim Related Installation Instructions	AV- prefix 667 Anti Vandal Trim Kit
Trim One Side Kit Installation <a href="#">Doc# A7028</a>	Lockbody/Trim Related Installation Instructions	
Dummy Trim (One Side) Installation <a href="#">Doc# A7036</a>	Lockbody/Trim Related Installation Instructions	8293 Function ONLY
7800 Knobs / 8200 Levers Mortise Lock & 3P8225 Levers Triad Lock with Escutcheon Trim - WT Designs Installation <a href="#">Doc# A7034</a>	Lockbody/Trim Related Installation Instructions	
Studio Collection Levers Installation Doc# A7986	Lockbody/Trim Related Installation Instructions	
BHL Trim Installation <a href="#">Doc# A8131</a>	Lockbody/Trim Related Installation Instructions	
BHD Trim Installation <a href="#">Doc# A8233</a>	Lockbody/Trim Related Installation Instructions	
BHW Trim Installation <a href="#">Doc# A8146</a>	Lockbody/Trim Related Installation Instructions	
Simpli™ Roseless Trim Installation Doc# A8030	Lockbody/Trim Related Installation Instructions	
Freewheeling Escutcheon Trim Installation <a href="#">Doc# A7334</a>	Lockbody/Trim Related Installation Instructions	
Sectional Trim with V Series Indicator Installation <a href="#">Doc# A8257</a>	Lockbody/Trim Related Installation Instructions	Outside: V10, V10F, V20, V20F, V30, V40, V50, V60 Inside: V01, V01F, V03, V04, V06 V10 + V01 = V11 (Same pattern applies across all other numbers)
VN1 Escutcheon Trim with V Series Indicator Installation <a href="#">Doc# A8260</a>	Lockbody/Trim Related Installation Instructions	Outside: V10, V10F, V20, V20F, V30, V40, V50, V60 Inside: V01, V01F, V03, V04, V06 V10 + V01 = V11 (Same pattern applies across all other numbers)
130 Thumbturn 184 Emergency Release Installation <a href="#">Doc# A5675</a>	Lockbody/Trim Related Installation Instructions	



**8200 Series Mortise Lock Installation Instructions (cont)**

Installation Instructions Name & Doc#	Installation Category	Installation Notes
Simpli™ Roseless Trim Installation <a href="#">Doc# A8030</a>	Lockbody/Trim Related Installation Instructions	
Freewheeling Escutcheon Trim Installation <a href="#">Doc# A7334</a>	Lockbody/Trim Related Installation Instructions	FE Trim
Electrolynx Retrofit Kit Installation <a href="#">Doc# A7738</a>	Electrical Related Instructions	
End-Of-Line Resistors for EcoFlex Mortise Locks Installation <a href="#">Doc# A8191</a>	Electrical Related Instructions	
EcoFlex Electrified Mortise Locks With High Security Monitoring Installation <a href="#">Doc# A8192</a>	Electrical Related Instructions	NAC- Trim
Electrified Functions and Monitoring Electrolynx Connector System Installation <a href="#">Doc# A7722</a>	Electrical Related Instructions	Electrified Functions: 70,71, 72, 73 Monitoring Prefixes: RX, LX, DX
Full Wave Bridge Rectifier Wiring Diagram <a href="#">Doc# A6652</a>	Electrical Related Instructions	
MELR Mortise Locks (Standard Levers)	Electrical Related Instructions	Motorized Electric Latch Retraction
MELR Mortise Locks (Studio Levers)	Electrical Related Instructions	Motorized Electric Latch Retraction
4399 Exit Button Installation <a href="#">Doc# A7864</a>	Electrical Related Instructions	
Door Position Switch Installation <a href="#">Doc# A7983</a>	Electrical Related Instructions	FRAME ONLY
Door Position Switch Installation <a href="#">Doc# A8005</a>	Electrical Related Instructions	HINGE ONLY
Weather Seal Conduit Installation <a href="#">Doc# A7721</a>	Electrical Related Instructions	52-2847
Controller Replacement Installation <a href="#">Doc# A8288</a>	Electrical Related Instructions	52-6085
Weatherization Kit Installation <a href="#">Doc# A8289</a>	Electrical Related Instructions	52-6084
IN100 Series EM01 Outside Escutcheon & Controller Replacement Installation <a href="#">Doc# A8293</a>	Electrical Related Instructions	
IN120 Passport 1000 P2 Series Wifi Enabled Installation <a href="#">Doc# WFMN10A</a>	Electrical Related Instructions	
IP-Enabled Quick Reference Guide <a href="#">Doc# WFMN3</a>	Electrical Related Instructions	
6300 Series Interchangeable Core Removal and Installation <a href="#">Doc# A5634</a>	Cylinder Related	LFIC
KESO F1 Mortise and Rim Cylinders Removable Core Installation <a href="#">Doc# A5687</a>	Cylinder Related	Mortise: 170 series Rim: 164 Series
677 & 2-677 Rabbeted Door Kits Installation <a href="#">Doc# A7066</a>	Misc. Instructions	



## 9200 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
<a href="#">Main Lock Template</a> <a href="#">Doc# 7057</a>	Mounting Template	This can be used for electrical and standard locks (Always Need This - Unless using Behavioral Health Trim)
<a href="#">Electrified Lock Template</a> <a href="#">Doc# 7065</a>	Electrified	Typically paired with Main Lock Template Doc# 7057 (FOR FUNCTIONS 70 THRU 73) & (PREFIXES: 56-, RX-, LX- & DX-) & (NAC-270/271/274/275/280/281)
<a href="#">Rose Trim Template</a> <a href="#">Doc# 7058</a>	Sectional/Roses	Works for all Roses (O, CO, TO, LN, CR, TR, E2, E3, E4, L, SN, SL) 9200 Only
<a href="#">Dummy Trim Template</a> <a href="#">Doc# 4298</a>	Sectional/Roses	Trim one side Kit Functions 93 & 94
<a href="#">Main Lock Template</a> <a href="#">Doc# 4482</a>	Mounting Template (Optional - Read Notes)	This is to be used with one side trim kit Functions 93 & 94
<a href="#">Thumbturn Template</a> <a href="#">Doc# 7059</a>	Sectional Accessories/ Indicators	7805, 7812, 7824, 7825, 7828, 7843, 7845, 7847, 7850, 7851, 7856, 7857, 7858, 7865, 7866, 7867, 7868, NAC-(78280, 78281, 78284, 78285)
<a href="#">LE1, LE3, LW1, CE, TE, KE1, KE3, KW1 Trim Template</a> <a href="#">Doc# 7052</a>	Escutcheon Trims	Exposed Screws
<a href="#">LE2, LE4, KE2, KE4 Trim Template</a> <a href="#">Doc# 7052</a>	Escutcheon Trims	Concealed Screws
<a href="#">LS &amp; KS Trim Template</a> <a href="#">Doc# 7054</a>	Escutcheon Trims	Security Screws
<a href="#">WT Trim Template</a> <a href="#">Doc# 7055</a>	Escutcheon Trims	Surface Applied
<a href="#">BHW Template</a> <a href="#">Doc# 4711</a>	Behavioral Health (Anti-Ligature)	Functions: 9204, 9205, 9206, 9215, 9216, 9217, 9224, 9225, 9226, 9235, 9237, 9238, 9239, 9240, 9241, 9242, 9243, 9245, 9249, 9250, 9255, 9259, 9265, 9266, 9270, 9271, 9272, 9273
<a href="#">BHD Template</a> <a href="#">Doc# 4745</a>	Behavioral Health (Anti-Ligature)	Functions: 9204, 9205, 9215, 9216, 9217, 9224, 9225, 9226, 9237, 9238, 9239, 9240, 9241, 9242, 9243, 9245, 9249, 9250, 9255, 9259, 9265, 9266, 9270, 9271, 9272, 9273
<a href="#">Curved/Straight Lip Strikes</a> <a href="#">Doc# 7064</a>	Strikes	
<a href="#">877 Open Back Strike Template</a> <a href="#">Doc# 4744</a>	Strikes	

## 9200 Series Mortise Lock Installation Instructions

Installation Instructions Name & Doc#	Installation Category
9200 with Rose Trim Installation <a href="#">Doc# A7146</a>	Lockbody/Trim Related Installation Instructions
KS and LS Escutcheon Trim Installation <a href="#">Doc# A7147</a>	Lockbody/Trim Related Installation Instructions
130 Thumbturn and 185 Emergency Release Installation <a href="#">Doc# A5675</a>	Lockbody/Trim Related Installation Instructions



**MORTISE LOCKS**

# Template and Installation Instruction Guide

91065

## M-9200 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
Main Lock Template Doc# <a href="#">4483</a>	Mounting Template	M- 9200 Only
<a href="#">Rose Trim Template</a> Doc# <a href="#">7058</a>	Sectional/Roses	Works for Roses: (L, LN, SN, SL) M- 9200 Only
<a href="#">Thumbturn Template</a> Doc# <a href="#">7059</a>	Sectional Accessories/Indicators	Functions: 9203, 9205, 9221, 9222, 9223, 9224, 9225, 9243, 9245, 9250, 9265, 9266
<a href="#">LE3 Trim Template</a> Doc# <a href="#">7052</a>	Escutcheon Trims	
<a href="#">LE4 Trim Template</a> Doc# <a href="#">7052</a>	Escutcheon Trims	Concealed Screws
<a href="#">LS Trim Template</a> Doc# <a href="#">7054</a>	Escutcheon Trims	Security Screws
<a href="#">BHD Template</a> Doc# <a href="#">4745</a>	Behavioral Health (Anti-Ligature)	Functions: 9204, 9205, 9215, 9216, 9217, 9224, 9225, 9226, 9237, 9238, 9239, 9240, 9241, 9242, 9243, 9245, 9249, 9250, 9255, 9259, 9265, 9266, 9270, 9271, 9272, 9273
<a href="#">Curved/Straight Lip Strikes</a> Doc# <a href="#">7064</a>	Strikes	
<a href="#">877 Open Back Strike Template</a> Doc# <a href="#">4744</a>	Strikes	

## M-9200 Series Mortise Lock Installation Instructions

Installation Instructions Name & Doc#	Installation Category
9200 with Rose Trim Installation Doc# <a href="#">A7146</a>	Lockbody/Trim Related Installation Instructions
KS and LS Escutcheon Trim Installation Doc# <a href="#">A7147</a>	Lockbody/Trim Related Installation Instructions
130 Thumbturn and 185 Emergency Release Installation Doc# <a href="#">A5675</a>	Lockbody/Trim Related Installation Instructions