



PED4000 Series

Template Guide

PED4200 Series Exit Device Templates

Template	Device
Mounting Template (Includes Fire Rated Devices) MEDT22	PED4210, PED4240, PED4245, PED4247, PED4249, PED4250, PED4255, PED4257, PED4259, PED42910, PED42930

Template	Strike
MEDT73	603 Strike
MEDT73	613 Strike
MEDT71	632 Strike
MEDT71	642 Strike
MEDT72	644 Strike
MEDT38	649 Strike
MEDT74	656 Strike
MEDT37	657 Strike
METD77	658 Strike
MEDT47	881 Strike

Template	Removable Mullions
MEDT77	CRAL600 Removeable Mullion

Template	Trims
800PT/900PT Trim Template MEDT19	PED4210, PED4240, PED4245, PED4247, PED4249, PED4250, PED4255, PED4257, PED4259
800PT/900PT Trim Template MEDT32	PED42910, PED42930
PT33 Trim Template T31212	PED4250, PED4257
PT34 rim Template T31222	PED4250, PED4258
PT35 Trim Template T31211	PED4250, PED4259
PT36 Trim Template T31282	PED4250, PED4260
PT37 Trim Template T31281	PED4250, PED4261
P12, P13, P14 Trim Template See Notes	See Installation Instructions
K157 Trim Template MEDT35	PED4257

Template	Quick Code
Quick Codes MEDT8	D, M61, M91, M92, M94, M97, MELR
Quick Codes MEDT32	M93



PED4000 Series

Template Guide

PED4600 Series Exit Device Templates

Template	Device
Aluminum & Metal Door Mounting Template MEDT45	PED4600 All Functions
Wood Door Mounting Template MEDT46	PED4600 All Functions

Template	Strike
MEDT50	908 Strike
MEDT50	C908 Strike
MEDT49	815 Strike

Template	Quick Code
Quick Codes MEDT17	D, M61, M91, M92, M94, M97, MELR
Quick Codes MEDT32	M93

Template	Trims
8M00PT/9M00PT Trim MEDT19	PED4610, PED4640, PED4645, PED4647, PED4649 PED4650, PED4655, PED4657, PED4659
8M00PT/9M00PT Trim MEDT32	PED46903, PED46905, PED46910, PED46930
PT33 Trim Template T31212	PED4610T, PED4650T, PED4655T, PED5657T
PT34 Trim Template T31222	PED4610T, PED4650T, PED4655T, PED5657T
PT35 Trim Template T31211	PED4610T, PED4650T, PED4655T, PED5657T
PT36 Trim Template T31282	PED4610T, PED4650T, PED4655T, PED5657T
PT37 Trim Template T31281	PED4610T, PED4650T, PED4655T, PED5657T

Template	Thermal Pin
MEDT28	Thermal Pin



PED4000 Series

**Corbin
Russwin**
ASSA ABLOY

Template Guide

PED5800 Series Exit Device Templates

Template	Device
Aluminum Door Mounting Template MEDT1	PED4800 All Functions
Metal Door Mounting Template MEDT3	PED4800 All Functions
Wood/Composite Door Mounting Template MEDT33	PED4800 All Functions

Template	Strike
MEDT9	606, 650, 652 Strikes
MEDT6	640 Strike
MEDT24	881 Strike

Template	Trims
800PT/900PT Trim Template MEDT48	PED4810, PED4840, PED4845 PED4849, PED4850, PED4855, PED4859
800PT/900PT Trim Template MEDT51	PED48910, PED48930
PED155, PED159 Trim Template MEDT7	PED4850T
P12, P13, P14 Trim See Notes	See Installation Instructions

Template	Quick Code
Quick Codes MEDT17	D, M61, M91, M92, M94, M97, MELR
Quick Code MEDT51	M93
Quick Code MEDT1, ref note 9	M55