

INSTALLATION INSTRUCTIONS

PART No. FB23070 & FB23071

Jeep® JK Wrangler
Step Sliders 4DR (FB23070) & 2DR (FB23071)



FB23071 Shown



VIDEO AVAILABLE



FB23070 Shown

REQUIRED TOOLS

16mm Socket
Socket Wrench

KIT CONTAINS

Step Slider, Left & Right

QTY

1 set

1) REMOVE CURRENT SIDE STEPS (IF APPLICABLE)

If you currently have factory or aftermarket side steps, remove them at this time.

NOTE:

The Fishbone Offroad Side Steps may work with some rocker guards. Check for clearance prior to removing rocker guards to possibly avoid additional steps.

2) INSTALL STEP SLIDERS

On the driver's side of the Jeep, use a 16mm socket to remove the two nuts on either side of the body mount bolt. DO NOT REMOVE THE JEEP'S BODY MOUNT BOLT. The Fishbone Step Sliders will install without removing the body mount bolt.



2307000

INSTALLATION INSTRUCTIONS

PART No. FB23070 & FB23071

**Jeep® JK Wrangler
Step Sliders 4DR (FB23070) & 2DR (FB23071)**

For 2DR vehicles, there will be two (2) body mount locations on each side. On 4DR vehicles, there will be three (3) locations on each side.

FB23071 Orientation Note:

To identify the front and rear of the part, which will help identify driver and passenger, see images below:

Passenger side shown



FRONT - Tube in middle

REAR - Tube on side

Once all nuts have been removed, lift the driver's side step into place. Reinsert all factory nuts to their recommended torque specs.



- 3) **REPEAT STEPS FOR PASS SIDE**
Repeat step 2 for the passenger side.
- 4) **ENJOY YOUR NEW FISHBONE OFFROAD STEP SLIDERS!**

