

# ADVANCE ADAPTERS INC.

P.O. Box 247, 4320 Aerotech Center Way

Paso Robles, CA 93447

Telephone: (800) 350-2223 Fax: (805) 238-4201

**P/N: 27-0011**

PAGE 1 OF 1

Page Rev. Date: 09-27-00

## **NP231 (23T)/CHEVY V8 TRANNY KIT NV4500/AX15 REPLACEMENT**

### **KIT CONSISTS OF:**

<b>No.</b>	<b>Qty</b>	<b>Part No.</b>	<b>Description</b>
1.	1 Kit	50-0204	NV4500 TO NP231 WRANGLER 23T KIT
2.	1	52-0221	GM INPUT SHAFT
3.	1 Kit	712576	NV4500-1996 GM BHSG ADAPT. KIT
4.	1 Kit	716008	WRANGLER CROSSMEMBER MOUNT
5.	1 Kit	716050D1	NV4500 SHIFT HANDLE ASSY
6.	1	716130	HYD. MASTER CYL. FITTING
7.	1	716130H	42" STAINLESS HOSE-3 FITTING
8.	1 Kit	716331	*JEEP SLAVE CYL. KIT

### **INSTALLATION NOTES:**

This kit is designed to fit the Dodge Standard Duty NV4500 transmission.

The front bearing retainer must be removed with the stock input shaft. Install the new GM style input shaft provided. The bearing retainer must be modified as listed on the 712576 Instruction Sheet.

**If you have a 1997-2000 TJ, you will be required to purchase P/N 716130TJ (Hydraulic master cylinder fitting).**

This is a parts pull sheet. Refer to the instruction sheet on each kit for proper installation.

**SPECIAL NOTE:** The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.