

## MOUNTING INSTRUCTIONS

5 SECTIONS TELESCOPIC ALUMINIUM WHIP

**1**

Pull out the sections of telescopic aluminium whip (1), insert the jointing sleeves (2) and lock them using the screws (3). Insert the top section with the cage (4) at L (see tuning table for frequency) and lock it using the screw (5) and 2 mm hexagonal key (6).

**NOTE:** Use the table just as a guide. For fine-tuning please use an SWR-meter

**2**

Fit the whip (1) on the bottom section (7). Well lock the hose clamps (12) by using the suitable 8mm open key.

**3**

Mount the bottom section with coil (7) on the mast using parts (8), (9), (10) and (11) in accordance to the picture.

Mast Ø 40-50mm (not supplied)

**4**

Mount the PVC cap (14) at the end of radials tubes (13) and lock them on the coil by using the suitable 10mm open key.