



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




**Peugeot 308 II Hatchback 5dr
(2013-2021)**

308HB II KPL

SOLARRIDE Zakonki, osłony przeciwsłoneczne do Peugeot 308 II Hatchback (2013-2021) KPL 3kg



5 904035 790965 >



4 x



2 x



