



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Skoda Octavia II Kombi (2004-2013)

O2K KPL

SOLARRIDE Zaklonki, osłony przeciwsłoneczne do Skoda Octavia 2 II Kombi (2004-2013) KPL 3lg



5 904035 790750 >



6 x



4 x



