

Trapezoidal 10-hole Installation Schematic



1. Check whether the accessories are complete.



2. Place the white plastic part into the circular hole on the back, with the straight line logo facing upwards and aligned with the outer hole.



3. Secure the base plate with screws, pay attention to the fact that the raised side of the base plate faces down.



4. Fixed middle stopper, toothed side facing backwards.



5. Fixed top plate, toothed side facing forward.



6. Assembly complete.