



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




**VW Volkswagen Passat B8 Sedan
(2014-2021)**

B8S DR

SOLARRIDE Zasklonki, osłony przeciwsłoneczne do VW Passat B8 Sedan (2014-2021) DR 2kg



5 904035 793898 >



6 x



