



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Skoda Superb III (2015-2023)

SUP3S DR

SOLARRIDE Zaškrtni rákosy pravejšieho zverhu Skoda Superb 3 II (2015-2023) Sedan DR2M 1lg



5 904035 790880 >



6 x



