



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Fiat Panda 2 II (2003-2012)

PANDA II KPL

SOLARRIDE Zaslonki, osłony przeciwsłoneczne do Fiat Panda II (2003-2012) KPL 3kg



5 904035 791054 >



4 x



4 x



