



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž



Volvo V70 III (2007–2016)

V70 III DR

SOLARRIDE Zasklení do Volvo V70 III (2007–2016) DRZWI 1kg



5 904035 793423 >




Volvo V70 III (2007–2016)

XC70 II DR

SOLARRIDE Zasklení do Volvo XC70 II (2007–2016) DRZWI 1kg



5 904035 793430 >



4 x





Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž

