



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




SEAT León I (1999-2005)

L1 KPL

SOLARRIDE Zasklonki, osłony przeciwsłoneczne do SEAT LEON I (1999-2005) KPL 3kg



5 904035 792679 >



6 x



2 x



