

CA290

A182JQ

A*12	B*12	C*60	D*3	E*3	F*4	G*2	H*30	I*4	J*1

Warm reminder: When installing, tighten the screws to about 70% and then tighten them a after the installation is completed!



