

# INSTALL GUIDE

---

The adhesive becomes stronger with time.

## FOR BEST RESULTS:

### PLEASE READ BEFORE USE!

To activate and achieve a **50% bond**, let the phone rest for **20 minutes**.

To achieve a **90% bond**, let the phone rest for **12 hours**.

---



### STEP 1

Remove film on all 2 adhesive stickers.

### STEP 2

Starting with the left side of the device, snap it into the outer corners of the case.

Apply pressure on the adhesive area to activate the bond.

### STEP 3

Right side install:  
Starting from the outer corners of the device, snap it into the outer corners of the case.

Apply pressure on the adhesive area to activate the bond.