



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž



Skoda Octavia II Kombi (2004-2013)

O2K BEZ KL

SOLARRIDE zastonki, oslony przeciwsłoneczne do Skoda Octavia 2 II Kombi (2004-2013) BEZ KL 2lg.



6 x



2 x



