

Fișă tehnică | Număr articol: 210-422

Stickers for operating instructions; for high-current terminal blocks; 285 Series

www.wago.com/210-422



The diagram illustrates the correct and incorrect ways to insert a wire into a WAGO terminal block. Step 1 shows the wire being inserted into the terminal. Step 2 shows the wire being pushed in. Step 3 shows the wire being inserted into the terminal block. Step 4 shows the wire being inserted into the terminal block. Step 5 shows the wire being inserted into the terminal block. The diagram also shows the correct way to insert a wire into the terminal block, with a red 'X' indicating an incorrect method. The dimensions of the wire are given as 35 - 36 mm (1.38 in). The part numbers are 285-172, 285-194, 285-195, 285-197, and 285-495. The material of the wire is specified as 285-197 = TS 35 x 2,3 mm Cu.

Date
Material Data

Weight	1,8g
--------	------

Supus modificărilor.

WAGO Kontakttechnik GmbH & Co. KG
/Representative Office Romania
Sos. Pipera-Tunari nr. 1/1
building 1, 2nd floor | 077190 Voluntari, Ilfov
Tel.: +40-(0)31 421 85 68 | Email: info-RO@wago.com

Aveți întrebări despre produsele noastre?
Vă stăm la dispoziție pentru preluarea apelului la +40 (0) 31 421 85 68.



Commercial data

Product Group	2 (Terminal Block Accessories)
Packaging type	BOX
Country of origin	DE
GTIN	4017332632478
Customs tariff number	39199080888

Counterpart

Installation Notes

Supus modificărilor.

WAGO Kontakttechnik GmbH & Co. KG
/Representative Office Romania
Sos. Pipera-Tunari nr. 1/1
building 1, 2nd floor | 077190 Voluntari, Ilfov
Tel.: +40-(0)31 421 85 68 | Email: info-RO@wago.com

Aveți întrebări despre produsele noastre?
Vă stăm la dispoziție pentru preluarea apelului la +40 (0) 31 421 85 68.