

Package Includes:

Paper Dispenser



Wood dowel



Rubber Feet



1. Expand legs until they click into place



2. Insert rubber feet into predrilled holes



3. Pull blade bar down until it clicks



4. Insert dowel into paper roll and place in cutter



5. To make a clean cut, pull paper straight up and tear from one side to the other



6. To collapse the cutter, push in on the inside leg to disconnect the indent

