



Noted:

1. The wedge is designed as a 3 mm door profile, the wall thickness of the profile is less than 2 mm, add wedge spacer adjustment. When the profile wall thickness is greater than 3 mm and the wedge wedges are tight, the wedge block will protrude from the upper and lower frame edges. At this time, do not use a hard wedge to prevent damage. The hinge block over the fan and hinge block under the fan, the protruding part is smoothed with an angle grinder.
2. After the wedge wedge is tight, the self-locking design is ensured, that is, the hinge block over the fan does not tighten the locking screw and the wedge does not exit. Fully guarantee the door fittings installation requirements.

BUY ON

www.cablematic.com