



ASCENTSTEP™ 5-1/2" RUNNING BOARDS

**INDUSTRY
EXCLUSIVE
SEAMLESSLY
BLENDED ENDS.**

**UNIQUE DUAL-
CONSTRUCTION
STEP PADS.**

New, innovative running boards offer a worthy accent for modern pickups and SUVs.



A new truck is a big investment. So when it comes to adding accessories, why settle for the same old look? ARIES AscentSteps™ offer uncommon elegance and innovative style with their teardrop profile, seamlessly blended ends and highly unique, dual-construction step pads.

- Stylish and modern teardrop design
- Aggressive, integrated step pads blend steel with non-skid, poly tread
- Polyethylene tread raised through stainless overlay for maximum traction
- Rigid steel construction with sleek, durable carbide black powder coat finish
- No-drill, vehicle-specific application for a custom fit
- VersaTrac® mounting system for easy installation and vehicle customization
- Three base lengths require less inventory
- Limited lifetime warranty



APPLICATION GUIDE

AcsentStep™ Running Boards

Make / Model	Style	Years	Brackets Only	Kit (Boards and Brackets)	Boards Only
			Bracket#	Carbide Black#	Carbide Black#
Chevrolet					
Colorado	Crew cab	15 - 19	2055104	2558044	2057985
	Extended cab	15 - 19	2055104	2558043	2057975
Silverado 1500	Crew cab	19 - 19	2055105	2558011	2057991
		07 - 18	2055101	2558047	2057991
	Extended cab	07 - 18	2055101	2558002	2057975
Silverado 1500 Legacy	Extended cab	19 - 19	2055101	2558002	2057975
Silverado 2500 HD / 3500 HD	Crew cab (diesel)	07 - 19	2055102	2558046	2057991
	Crew cab (gas)	07 - 19	2055101	2558047	2057991
	Extended cab (diesel)	07 - 19	2055102	2558021	2057975
	Extended cab (gas)	07 - 19	2055101	2558002	2057975
Suburban	--	15 - 18	2055101	2558047	2057991
Tahoe	--	05 - 18	2055101	2558002	2057975
Dodge					
Ram 1500	Crew cab	09 - 10	2055111	2558006	2057985
	Extended cab	09 - 10	2055111	2558005	2057975
Ram 2500 / 3500	Crew cab	09 - 10	2055111	2558006	2057985
	Extended crew cab	09 - 10	2055111	2558005	2057975
Ford					
F-150	Crew cab	04 - 14	2055120	2558009	2057985
		15 - 19	2055121	2558048	2057991
	Extended cab	04 - 14	2055120	2558008	2057975
		15 - 19	2055122	2558012	2057975
F-250	Crew cab	99 - 99	2055124	2558024	2057991
	Extended cab	99 - 99	2055123	2558014	2057975
F-250 / F-350 Super Duty	Crew cab	17 - 19	2055121	2558048	2057991
		99 - 16	2055124	2558024	2057991
	Extended cab	17 - 19	2055122	2558012	2057975
		99 - 16	2055123	2558014	2057975
F-450 Super Duty	Crew cab	99 - 16	2055124	2558024	2057991
GMC					
Canyon	Crew cab	15 - 19	2055104	2558044	2057985
	Extended cab	15 - 19	2055104	2558043	2057975
Sierra 1500	Crew cab	19 - 19	2055105	2558011	2057991
		07 - 18	2055101	2558047	2057991
	Extended cab	07 - 18	2055101	2558002	2057975
Sierra 1500 Limited	Extended cab	19 - 19	2055101	2558002	2057975
Sierra 2500 HD / 3500 HD	Crew cab (diesel)	07 - 19	2055102	2558046	2057991
	Crew cab (gas)	07 - 19	2055101	2558047	2057991
	Extended cab (diesel)	07 - 19	2055102	2558021	2057975
	Extended cab (gas)	07 - 19	2055101	2558002	2057975
Yukon	--	05 - 18	2055101	2558002	2057975
Yukon XL	--	15 - 18	2055101	2558047	2057991
Honda					
Ridgeline	--	17 - 18	2055130	2558030	2057985

Applications continued on the following page

AcsentStep™ Running Boards

Make / Model	Style	Years	Brackets Only	Kit (Boards and Brackets)	Boards Only
			Bracket#	Carbide Black#	Carbide Black#
Nissan					
Titan	Crew cab	04 - 19	2055142	2558042	2057985
	Extended cab	04 - 18	2055142	2558045	2057975
Titan XD	Crew cab	16 - 19	2055142	2558042	2057985
Ram					
1500	Crew cab	19 - 19	2055117	2558007	2057991
		11 - 18	2055111	2558006	2057985
	Extended cab	19 - 19	2055117	2558004	2057975
		11 - 18	2055111	2558005	2057975
1500 Classic	Crew cab	19 - 19	2055111	2558006	2057985
	Extended cab	19 - 19	2055111	2558005	2057975
2500 / 3500	Crew cab	11 - 18	2055111	2558006	2057985
Toyota					
Tacoma	Crew cab	05 - 19	2055152	2558023	2057985
Tundra	Crew cab	07 - 19	2055151	2558019	2057985
	Extended crew cab	07 - 19	2055151	2558019	2057985