

# IMPACT™ SHOCK-ABSORBING REAR BUMPER STEP



**NON-SKID  
9-1/2" STEP.**

**SHOCK  
ABSORBING.**

**FLEET  
APPROVED.**



- Designed to absorb rear impacts up to 5mph and avoid possible frame damage
- Ideal for delivery and cargo vans that frequently back into loading docks
- Spring-loaded shock-absorbers built into the mounting brackets
- Integrated 9-1/2" wide stepping surface for easier rear vehicle access
- Fleet-approved, expanded steel treads for maximum traction and safety
- Reinforced, heavy-wall steel tube construction for superior strength
- Dual A-coat with gloss black powder coat finish for exceptional rust resistance
- Universal bumper design with vehicle specific shock assembly for custom fit
- Designed to accept optional aftermarket parking sensors (not included)
- Limited lifetime warranty

## Impact Absorbing Brackets



Designed to absorb rear impacts up to 5mph and avoid possible frame damage



Ideal for delivery vans and cargo vans that frequently back into loading docks



# IMPACT™ SHOCK-ABSORBING REAR BUMPER STEP



## Impact Absorbing Brackets



Spring-loaded shock-absorbers built into the mounting brackets



Designed to absorb rear impacts up to 5mph and avoid possible frame damage



Ideal for delivery vans and cargo vans that frequently back into loading docks

Make / Model	Years	Foot Notes	Kits (Bumper and Brackets)	Kit Price	Bumper Only	Bumper Price	Bracket / Spring Assembly Only	Bracket Price
<b>Dodge</b>								
Sprinter 2500	07 - 09	2, 3	415358-571500		415358		571500	
Sprinter 3500	07 - 09	2, 3	415358-571500		415358		571500	
<b>Ford</b>								
Transit-150	15 - 19	1, 2, 3	415358-571501		415358		571501	
Transit-250	15 - 19	1, 2, 3	415358-571501		415358		571501	
Transit-350	15 - 19	1, 2, 3	415358-571501		415358		571501	
<b>Freightliner</b>								
Sprinter 2500	07 - 19	2, 3	415358-571500		415358		571500	
Sprinter 3500	07 - 19	2, 3	415358-571500		415358		571500	
<b>Mercedes-Benz</b>								
Sprinter 2500	10 - 19	2, 3	415358-571500		415358		571500	
Sprinter 3500	10 - 19	2, 3	415358-571500		415358		571500	
<b>Ram</b>								
ProMaster 1500	14 - 20	2, 3	415358-571502		415358		571502	
ProMaster 2500	14 - 20	2, 3	415358-571502		415358		571502	
ProMaster 3500	14 - 20	2, 3	415358-571502		415358		571502	

1. Remove factory bumper      2. Excluding factory receiver      3. Will interfere with parking sensors