

## 1100-01

### GEDORE L-BOXX® 136

### WITH ASSORTMENT

### MECHANIC

58 pieces

- > Suitable for tradesmen
- > A selection of essential tools
- > With Check-Tool insert for quick check of completeness
- > 1100 CT2-01 to retrofit existing L-BOXX®es 136



1100-01



1100 CT2-01

Contents	kg	Code	No.	Contents	kg	Code	No.
1993 U-20 1990-10 1995 19 10 11 12 13 14 15 16 17 18 19 21 22 24 60 CP 8 142 10 JC 8316-160 JC 8133-180 JC 600 H-500 110-256 45 S TFK 649 E-649 F 0063-08 H 42-10 SCL 43 TX-80 VDE 2170-2160 PH-077 4615 3 4533-2 8728 + 1100 L	8.3	2658194	1100-01	1993 U-20 1990-10 1995 19 10 11 12 13 14 15 16 17 18 19 21 22 24 60 CP 8 142 10 JC 8316-160 JC 8133-180 JC 600 H-500 110-256 45 S TFK 649 E-649 F 0063-08	6.8	2936828	1100 CT2-01
Description	kg	Code	No.	Description	kg	Code	No.
Foam insert 2/2 L-BOXX 136, empty	0.200	2690055		Foam insert 2/2 L-BOXX 136, empty	0.200	2690055	EI-1100-01

## 1100-02

### GEDORE L-BOXX® 136

### WITH ASSORTMENT

### ELECTRICIAN

36 pieces

- > Particularly suitable for electricians
- > A selection of essential tools
- > With Check-Tool insert for quick check of completeness
- > 1100 CT2-02 to retrofit existing L-BOXX®es 136



1100 CT2-02



1100-02

Contents	kg	Code	No.	Contents	kg	Code	No.
110-256 112-2510 600 H-500 60 CP 8 142 10 JC 8097 8133-180 JC VDE 8314-160 H VDE 8132-200 H VDE 8132 AB-200 H VDE 8098-160 H VDE 8094 4528 4629 0175-06 H 42-10 VDE 2170-2160 PH-077 4615 3 VDE 4616 45 E 4533-2 + 1100 L	7.7	2658208	1100-02	110-256 112-2510 600 H-500 60 CP 8 142 10 JC 8097 8133-180 JC VDE 8314-160 H VDE 8132-200 H VDE 8132 AB-200 H VDE 8098-160 H VDE 8094 4528 4629 0175-06	6.1	2936836	1100 CT2-02
Description	kg	Code	No.	Description	kg	Code	No.
Foam insert 2/2 L-BOXX 136, empty	0.200	2690047		Foam insert 2/2 L-BOXX 136, empty	0.200	2690047	EI-1100-02