



- 1.) Strip cable jacket 20mm.
- 2.) Strip conductors 8mm.
- 3.) Pass cable through gland nut, gland and cover.
- 4.) Insert stripped wire into screw-in pin, tighten. [2.0 Nm]
- 5.) Assemble gland nut into cover, tighten. [2.0 Nm]
- 6.) Type 600VAC

Number of cond.	AWG Size	Jacket OD(mm)
3	8	21mm

- 7.) A Marking: Not for interrupting current

The RS PRO Seal of Approval is only awarded after a rigorous quality process to demanding international standards.