



Instruction Leaflet

UHF Clamp Plug

RS stock no. 546-2582

Assembly instructions

1. Place coupling nut over cable, as shown.
2. Trim from cable the outer sheath, braid and dielectric, to dimensions indicated.
3. Tin exposed braid and centre conductor.
4. Screw body sub-assembly, onto the cable as far as it will go.
5. Solder braid to body sub-assembly, then centre conductor to contact.
6. Screw coupling nut forward over body sub-assembly.

Figure 1

