



1. Set the lock to its factory presetting 0-0-0 by lining up all the digits next to the marks in the middle of the dial.
2. Turn the shackle a quarter turn (90°) so that the lock is fully open.
3. Press the shackle down into the body of the lock.
4. Set your own personal combination.
5. Lift the shackle up out of the lock body again. Turn the shackle back to the fully-open position. Your new code is now set.