

Directly buried tube installation

1. Directly buried depth

Dig a hole. Size: length: 50 * Width 50 * depth 50cm
(As the photo)

2. Fill 10cm thickness concrete on the bottom first.
mixing ratio of concrete is
cement:sand:crushed stone=1:2:3.5

3. After fill 10cm thickness concrete, then
put the pillar, to fill more 40cm depth to
fullfill the hole to made the tube steady.

4. After finish intall. Let it
curing 7 days. then can use.

