



= existing studwork



= wood face block (noggins) to provide extra strength/support



= Horizontal Screw holes to fix speaker into woodwork



= Vertical Screwholes holes to fix speaker into woodwork



= Min 241 mm clearance required for 12" On Centre width installation