

53285**COFFRET DE CALAGE POUR VAG 2.4, 2.5, SDI, TDI****DÉTAILS**

Outils OEM

T10025/3248/3419, T50009, 2064, 2065A, 3355

Marques

VW Crafter (06-13), LT (96-06), Transporter (90-03)

Code moteur

2.4D AAB, AJA

2.5D SDI AGX

2.5D Tdi ACV, AHD, AHY, AJT, ANJ, APA, AUF, AVR, AXG, AXL, AYC, AYY,

BBE, BBF

2.5D TDiCR BJJ, BJK, BJL, BJM

APP

VAG 2.4, 2.5 SDI, TDI

OEM**MP 1 300****T10025****U40021****2065A****21 105****3355****3419****5190****999 5190****999 5649****MOTORES**

ACV

AGX

AHD

AHY

AJT

ANJ

APA

AUF

AVR

AXG

AXL

AYC

AYY

BBE

BBF

D5252T

