

ref. 53293

DRAFT KIT



Function

This shim kit is designed for Ford vehicle adjustments and distributions.

Advantages

- ✓ Light weight (4.15 kg)
- ✓ Practical carrying and storage case with protective foam

Brands

FORD: B-Max (12-17), C-Max (07-17), Cougar (98-01), Courier (00-02), Escort (94-98), Fiesta (95-17), Focus (98-17), Focus C-Max (03-07), Fusion (02-12), Galaxy (06-15), Grand C-Max (10-17), Kuga (08-15), Maverick (01-07), Mondeo (93-15), Orion (94-94), Puma (97-02), S-Max (06-15), Tourneo Connect (02-15), Transit (06-11), Transit Connect (02-16), EcoSport (13-15), Tourneo Courier (14-15), Grand Tourneo Courier (13-15).

OEM tools

303-376 (21-162B), 303-1059, 303-193 (21-104), 303-393-01, 303-1054, 303-1097, 303-748, 303-734 (21-262), 303-651 (21-229), 303-393A (21-168), 303-393-02, 303-507 (21-210), 303-620 (21-163), 303-732 (21-260), 303-735 (21-263)

Contains

1.25 16v Belt, 1.4 16v Belt, 1.4D TDCi Belt, 1.5 EcoBoost Belt, 1.6Ti-VCT Belt, 1.6 Ecoboost Belt, 1.6D TDCi Belt 1.6D, TDCi ECONetic Belt, 1.8 16v Belt, 1.8 16v Belt, 1.8D TDCi Belt, 1.8D TDdi Belt, 1.8D TCI Belt, 1.8D Turbo Belt, 2.0 16v Belt, 2.0 16v Belt, 2.0D TDCi Belt, 2.2D TDCi Belt, 2.3 16v Belt, 2.3 16v Chain

