



ref. 54135

BRAKE CALLIPER SOCKET SET

Function

Designed for uninstalling the brake callipers when replacing brake pads.

Contents

Hexagonal bit sockets (7 PCS):

9x20mm (1/4"): Mercedes-Benz ML320 (2 PCS)

7x24mm, 8x24mm (3/8"): Mercedes-Benz Class C, Audi TT (2007-), A4 (2001-), A6 (2005-), A8 (2003-)

9x50mm (3/8"): Mercedes-Benz, BMW, Jaguar XF.

7x70mm, 7x92mm (3/8"): BMW Series 3 (E36) / Serie 5, Ford Mondeo, Fiesta, Alfa Romeo, Vauxhall, Volkswagen, SAAB, Chrysler, BMW Mini

11x100mm (3/8"): Mercedes ML, Ford Focus / Edge

1/2" Special sockets for brake calliper (5 PCS):

11.5x38mm (10-points): Porsche.

15x38mm (10-points): Audi Q7 / S8, Porsche Macan, Cayenne, Cayman.

20x38mm (10-points): Audi A8 / S6, Porsche Cayenne.

22x38mm (7-points): Audi S5.

14x38mm (7-points): Audi A5, A6L, Q5, Q7 (2017-)

1/2" Pentagon sockets (4 PCS): 10, 12.5, 14, 19mm

1/2" Bit drive (1 PC): 10mm





Applications

Audi: TT (2007-), A4 (2001-), A6 (2005-), A8 (2003-), Q7, S5, S6, S8

Porsche: Cayenne, Macan, Cayman

Mercedes-Benz: ML320, Clase C

Ford: Mondeo, Fiesta, Focus, Edge

BMW: Series 3 (E36 generation) / 5

Alfa Romeo

Jaguar: XF

Vauxhall

Volkswagen

Chrysler

Mini

SAAB