



ref. 54288

KIT DE CALADO PSA 1.2 GDI PURETECH

Herramientas OEM		
Citroen	Peugeot	Vauxhall
<ul style="list-style-type: none">• 0109-6• 0109-2B0109-2C• 0109-2D• 0197-N	<ul style="list-style-type: none">• 0109-6• 0109-2B0109-2C• 0109-2D• 0197-N	<ul style="list-style-type: none">• EN-52127-2

**Códigos de motor**

1.2 VTi: 1PP(HM01), EB2 (HMZ), EB2DTS(HNY), EB2 (HMW), EB2M (HMY),

EB2 (HMZ), EB2DTS(HNY), HMP (EB2FB), HMT(EB2D), HMU(EB2D),

HMV (EB2M), HMY (EB2M), HMZ (EB2), HMZ (EB2D), HMZ (EB2F),HMZ (EB2FB)

1.2 E-VTi: HMZ (EB2F), EB2F (HMZ)

1.2 PureTech THP: HNZ (EB2DT)

1.2 PureTech VTi: EB2ADS (HNS), EB2D(HMT), EB2ADJ (HNP),

EB2ADT (HNK), EB2ADTX (HNN), EB2DTS (HNW), EB2DTM (HNV),

EB2DTSM (HNW), EB2FA (HMR), EB2FAD (HMH), EB2FAD (HMM),

EB2DT (HNZ), EB2F (HMX), EB2F (HMT), EB2F(HMZ), EB2DTS(HNY),

EB2M(HMY)

Aplicaciones

Citroen: Berlingo IV (18-20), C1 II (14-18), C3 III (12-17), C3 IV (16-18), C4 Cactus (14-20), C4 Aircross (18-20), C-Elysee (12-18), DS3 (12-18) Peugeot: 108 (14-18), 208 (12-21), 2008 (13-21), 301 (12-20), 308 (13-21), 3008 (16-21), 508 (19-21), 5008 (14-21), Partner III (15-18) Partner IV (18-21) Rifter (19-21) Toyota: Aygo (14-18) GM: Crossland X (17-20), Combo E (18-20), Grandland X (17-20).