



ref. 54288

Psa 1.2 GDI PURETECHE SHIM KIT

OEM Tools		
Citroen	Peugeot	Vauxhall
<ul style="list-style-type: none">• 0109-6• 0109-2B0109-2C• 0109-2D• 0197-N	<ul style="list-style-type: none">• 0109-6• 0109-2B0109-2C• 0109-2D• 0197-N	<ul style="list-style-type: none">• EN-52127-2

**Engine codes:**

1.2 VTi: 1PP(HM01), EB2 (HMZ), EB2DTS(HNY), EB2 (HMW), EB2M (HMY),
EB2 (HMZ), EB2DTS(HNY), HMP (EB2FB), HMT(EB2D), HMU(EB2D),
HMV (EB2M), HMY (EB2M), HMZ (EB2), HMZ (EB2D), HMZ (EB2F),HMZ (EB2FB)

1.2 E-VTi: HMZ (EB2F), EB2F (HMZ)

1.2 PureTech THP: HNZ (EB2DT)

1.2 PureTech VTi: EB2ADS (HNS), EB2D(HMT), EB2ADJ (HNP),
EB2ADT (HNK), EB2ADTX (HNN), EB2DTS (HNW), EB2DTM (HNV),
EB2DTSM (HNW), EB2FA (HMR), EB2FAD (HMH), EB2FAD (HMM),
EB2DT (HNZ), EB2F (HMX), EB2F (HMT), EB2F(HMZ), EB2DTS(HNY),
EB2M(HMY)

Applications:

Citroen: Berlingo IV (18-20), C1 II (14-18), C3 III (12-17), C3 IV (16-18),C4 Cactus (14-20), C4 Aircross (18-20), C-Elysee (12-18), DS3 (12-18)Peugeot: 108 (14-18), 208 (12-21), 2008 (13-21), 301 (12-20), 308 (13-21), 3008 (16-21),508 (19-21), 5008 (14-21), Partner III (15-18) Partner IV (18-21) Rifter (19-21)Toyota: Aygo (14-18) GM: Crossland X (17-20), Combo E (18-20), Grandland X (17-20).