

Tool Needed: 2.5mm Hex Key

..kuat..[®]
(koo-at)

1. Remove the 4mm screw with a 2.5 mm hex key.
2. Slide the front tire tray out of the tray.

