

Tool Needed: 6mm Hex Key

..kuat..[®]
(koo-at)

1. Remove the 8mm bolt and ratchet pawl with the 6mm hex key.
2. Slide the rear tire cradle up and out.
3. Slide the base out.

