

Tools Needed: 6mm Hex Key

1. Remove the 8mm bolt with the 6mm hex key.
2. Slide the rear cradle up and out. Remove the base out of the tray.
3. Slide the tray extender into the rack. Using the existing 8mm x 110mm bolt, 8mm washer, parts (a) & (b), and 8mm lock nut, bolt sleeve to tighten down the extension.
4. Install the rear tire cradle into the extension. Using the 8mm x 105mm bolt that came in part kit, slide through part (a), the tray, tire cradle, Part (b), and tighten into the ratchet.

Note: You will not reuse the base.

kuat[®]

