Tool Needed: 6mm Hex Key
Prep: Turn the rack upside down.

1. Remove the 8mm bolt, and nut with a 6mm hex key.
2. Remove the rear cap.

..küat..®
(koo-at)