

Tools Needed: 8mm & 6mm Hex Key

..kuat..
(koo-at)

1. Remove the 10mm bolt from the front tire tray with a 8mm hex key.
2. Remove four 8mm bolts from the mounting plate with a 6mm hex key.

