

Tool Needed: 6mm Hex Key

..kuat..[®]
(koo-at)

1. Remove two 8mm bolts and nuts with a 6mm hex key on the tray you are replacing.
2. Slide the trays straight out of the center beam.

