

Tool Needed: 6mm Hex Key
Prep: Remove the Trail Doc from the rack.

1. Remove the 10mm bolt with a 6mm hex key.
2. Slide the Trail Doc cap up and out.

