

Tool Needed: 6mm Hex Key  
Prep: Remove the Trail Doc from the rack.

**..kuat..**<sup>®</sup>  
(koo-at)

1. Remove the 10mm bolt and lock washer from the Trail Doc cap.
2. Remove two 8mm bolts and lock nuts with a 6mm hex key from the front and rear tire trays.
3. Slide the bar out of the center beam.

