

Tool Needed: 5mm Hex Key, Flat Head Screwdriver

# *kuat*<sup>®</sup>

1. Using the 5mm Hex Key, remove 6mm bolt, split washer and washer.
2. Pull down to slide mount out.
3. Remove plastic spacer from mount.
4. Using a flat head screwdriver or pry tool, push in at locations shown to remove the plastic insert.
5. Repeat all steps in reverse to install new insert and mount.

